

3745-68-45 General operating requirements.

During start-up and shut-down of an incinerator, the owner or operator must not feed hazardous waste unless the incinerator is at steady state (normal) conditions of operation, including steady state operating temperature and air flow.

Effective: 01/07/1983

119.032 review dates: Exempt

Promulgated under: 119.03

Statutory authority: 3734.12

Rule amplifies: 3734.12

Prior effective dates: 04/15/1981